


# User Manual



**WARNING!** Do not remove the plastic bag unless you have finished the trip or seen the Run(blue) LED solid.

## START

Press the button for 5 seconds till both LED light up, the LED will then flash every 3 seconds indicating the logger is working.

## MAKE A MARK

Press the button once, the RUN LED will light up for 1 second, indicating a MARK has been made successfully. Total 8 MARKs can be made.

## STOP

- 1) press button for 5 seconds till LED light and Run LED flash for a while indicating report generating, and become solid indicating the logger has been used.
- 2) being plugged into the USB port of your device (PC, laptop, tablet or printer).
- 3) when data logger reaches maximum data storage

## GET THE REPORT

Plug USB into computer/laptop, if the device has stopped before plugging, a flash disk will pop up immediately with an encrypted PDF report; B, if the device is stopped by USB, you might have to wait a while till the RUN LED become solid, and then a flash disk will pop up with an encrypted PDF report.